


Henger Pendant Installation Instructions




Product Specifications

Model No.	HV5898T-BLK	HV5898T-WHT	HV5899T-BLK	HV5899T-WHT
Name	Henger			
Material	Aluminium			
Colour	Black	White	Black	White
Installation Type	Ceiling - Surface Mounted			
IP Rating	IP65			
Input Voltage	240v			
Protection Class	1 (Requires Earth) ⚡			
Lamp Base	Built in LED			
Lamp Wattage	1x 6w		1x 9w	
Colour Temp	TRI-Colour - 3000k, 4000k, 5500k		TRI-Colour - 3000k, 4000k, 5500k	
Lumens	480lm, 520lm, 500lm		720lm, 760lm, 740lm	
CRI	> 80			
Wiring	Parallel			
Dimmable	No			
Warranty	3 Years Replacement*			


Mounting Base Dimensions



HV5898 Dimensions



HV5899 Dimensions



Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

Steps for Installation:

1. Make sure that the electrical circuit is free of voltage (master switch off)
2. Loosen allen screws on side of base and separate mounting bracket from fitting.
3. Install the backing plate securely using appropriate screws for application.
4. Adjust cable to desired length and remove excess.
5. Connect the cable: Use wire with earth, connect earth first then positive and then neutral
6. Reattach fitting to base and tighten allen screws.
7. Fitting is preset to 3000k, To change loosen allen screws at top of pendant
8. Slide switch located inside to desired colour temperature
9. Reattach Pendant and tighten allen screws.
10. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road
Matraville NSW 2036
Australia

Tel: 02 9381 8300
Fax: 02 9666 8881
Email: sales@havit.com.au
Web: www.havit.com.au

Warranty Terms & Conditions*



Additional Information

