

		ITEST3760 MODEL			
		L	LR	LRC	LRM
Class I		•	•	•	•
Class II		•	•	•	•
Extension Leads		•	•	•	•
Pass/Fail	Test Results displayed along with PASS/FAIL	•	•	•	•
Test Fail	Flashing Red Warning Indicator	•	•	•	•
Mains	Wiring Safety Check	•	•	•	•
NO/NC Alert	Appliance Not Connected or Switched On Alert	•	•	•	•
Continuity		•	•	•	•
Insulation	250/500V	•	•	•	•
Polarity	Extension Lead Test	•	•	•	•
Meter Mode	Watts, Volts, Amps, VA	•	•	•	•
Leakage			•	•	•
RCD	Trip Time		•	•	•
	Ramp Test		•	•	•
Power Test	Power Factor, VA, Volts, Amps			•	•
Connectivity	Interface via USB to connected PC			•	•
Software	Included			WinPATS Base	WinPATS Memory Base
Memory	Stores 5,000 Test Results (downloadable to PC)				•
20A	Suitable for testing up to 20 Amps				ITEST3760XLM

Optional Accessories

ITESTEST1000	Earth Strap 1 metre long used to wrap around the appliance under test to cover a greater testing surface for the connection of the earth lead
ITESTEWL	Earth Bond Lead and Clip
ITESTXL	Extension Lead Adaptor
ITESTISOTII	Isolation Transformer 10A 240V AC used to avoid tripping the installation RCD
ITESTISOTAD	Isolation transformer adaptor to allow up to a 20A plug to be used with the isolation transformer maximum 10A load.
ITESTCL	IEC to Clover Leaf adaptor
ITESTF8	IEC to Figure Eight adaptor
ITEST3PA	Single phase to 1x 3 Phase adaptor up to 32A (3 Phase plug configuration required when ordering)
ITEST3MPA	Single phase to 2 x 3 Phase adaptors up to 32A (3 Phase plug configuration required when ordering)

Software

ITESTLOGBK	Stand- alone electronic log book for record keeping
WinPATS	Full version software for ITEST3760LRC allowing multiple sites and unlimited recording of test results (ITEST3760LRC must be connected to Laptop/P.C.)
WinPATSMEM	Full version software for ITEST3760LRM allowing multiple sites and unlimited recording of test results. (Data can be up/downloaded to or from ITEST3760LRM any time)

