


Stor Installation Instructions



Product Specifications		
Model No.	HV3670T-BLK	HV3671T-BLK
Name	Stor	
Material	Aluminium	
Colour	Black	
Installation Type	Wall or Ceiling	Wall
IP Rating	IP54	
Protection Class	1 (240v Requires Earth) 🕒	
Input Voltage	240v AC	
Lamp Base	Built in LED	
Lamp Wattage	1x 30w	
Colour Temp	TRI Colour - 3000k, 4000k, 5500k	
Lumens	2250lm, 2325lm, 2400lm	2050lm, 2125lm, 2250lm
CRI	> 80	
Wiring	Parallel	
Dimmable	No	
Warranty	3 Years Replacement*	







Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- · All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Remove allen screws from front of fitting and remove cover.
- 3. Connect the cable Use wire with earth; connect the earth first, then live and neutral wire.
- 4. Cover connections using an adhesive lined heat shrink or gel cap to make connection watertight. Failure to do this will void warranty.
- 5. Heat the heat shrink or crimp the gel cap making sure all connections are covered.
- 6. Install base plate to wall or ceiling dependant on model chosen in desired location using appropriate screws for application.
- 7. Seal all holes including cable entry and around screws.
- 8. Fitting is preset to 3000k, to change slide switch located on front of PCB to desired colour temperature.
- 9. Reattach cover to base plate making sure allen screws are tight to avoid any water penetration.
- 10. Apply silicon around edge of fitting to prevent any water from getting inside to electrical connections.
- 11. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road
Matraville NSW 2036

Australia

Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au







