

POWER ANALYZER 3390

Power measuring instruments



■ Maximum accuracy of ±0.16% achieved with current sensors!

- ☐ Measure the primary and secondary sides of inverters
- ☐ Advanced motor analysis functions
- Measure inverter noise



Large Assortment of Wide-band, High-Precision Feed-Through Current Sensors

4 Models **Effect of conductor position Effect of external** electromagnetic field **Completely Minimized**
















Current Sensor Method

Surpasses the Accuracy of Direct Connection Method



Power Analyzer 3390

When combined with the feed-through current sensors

Maximum accuracy of $\pm 0.16\%$



For Current Sensor specifications, please go to

page 15

Power Analyzing Control Engine **Technology processes**



Measurement data at high speeds and with excellent accuracy

Weight & Volume

A HIOKI proprietary engine that takes advantage of the latest semi-conductor technologies enables a much smaller footprint than ever before (in comparison with other HIOKI high performance power meters)

Feed-through current sensors

9709



CT6862



Clamp-on sensors

9272-10

Current sensor design allows for safe and efficient testing

- Choice of sensors include easy-to-measure AC and AC/DC clamp-on sensors and feed-through current sensors for highaccuracy measurements
- Immune to in-phase noise effects when measuring inverters

Basic accuracy of Model 3390: ±0.1%

Basic measurement range: DC, 0.5 Hz to 5 kHz

(Frequency bandwidth: DC, 0.5 Hz to 150 kHz)

Effective input range: 1% to 110%

- High accuracy, wide band, and wide dynamic range
- Also measure the secondary side of DC inverters in conjunction with a variety of HIOKI current sensors

All data updated at 50ms*

- 50ms data refresh rate for all measurements unaffected by settings restraints
- Synchronize the measurements of multiple 3390s Automatic update rate eliminates the need of switching for low-frequency measurements
- * 50ms data refresh rate does not apply to waveform and noise analysis

Meet the Needs of Alternative Energy and Inverter or Motor Evaluations

4-channel isolated input

Measure the primary and secondary sides of inverters simultaneously

- Choose wiring from single-phase two-wire to three-phase four-wire
- Synchronize the measurements of multiple 3390s



- Connect up to four **3390**s and synchronize their clocks and measurement timing for multiple-channel measurements (using the SYNC terminal and Connection Cable **9683**)
- Use dedicated application software to conduct synchronized operations for up to 4 units and obtain all the measurement data

CF card interface

& USB memory interface

Automatically save interval measurement data to a CF card (When saving manually, measured data and waveform data can be saved directly to the CF card and USB memory)



Connect an External Thermometer

• Data from temperature measurements taken with an external thermometer aids in motor evaluation

Connecting the **3440 SeriesTemperature HiTESTER**(via the RS-232C interface)

also allows temperature data to be collected simultaneously



Waveform Output and 16 Channel D/A output

- Use the **D/A OUTPUT OPTION 9792** to update data every 50ms and output up to 16 items in analog format
- Also output the voltage and current waveforms for each channel (using 1 to 8 channels)
 (Waveforms are output at 500 kS/s and sinusoidal waveforms can be represented accurately at up to 20 kHz)



Ideal for Motor Evaluation and Analysis

• Use of the **MOTOR TESTING OPTION 9791 (or 9793)** allows torque meter output and rotation input, and facilitates motor power measurement

For motor evaluation and analysis specifications, please go to pages 8 & 9

A Variety of Interfaces Standardly Equipped

Includes 100Mbps Ethernet and USB 2.0 High Speed communications interfaces.




HTTP server function available with free dedicated PC software

- HTTP server function through web browser enables easy remote operation
- Free dedicated PC application can be downloaded from the HIOKI website

Collect data and operate the **3390** remotely by connecting it to a PC via LAN or USB






Extra-Large Screen Expands Possibilities

Capture measured data and waveforms at a glance utilizing a variety of display options


The 9" color LCD can display up to 32 data parameters






Wiring check function prevents connection errors

Display connection and vector diagrams on the Wiring screen Improve efficiency and reliability while saving time in wiring even for three-phase measurements



Display just the required data in an easy-to-read graphic interface on the Select screen Screen_displaying_32,_16_8, or_4_items

Display items can be set individually for each selected screen Read data quickly and easily by just switching between the screens




All data is processed in parallel simultaneously.

A wealth of data analysis functions all built-in and ready to use.

Channel display

RMS and MEAN values, and AC, DC, and fundamental waveform components can be measured and displayed simultaneously








Vectors display

Measured voltage, current, and power on channels 1 to 4 as numerical values and as vectors

Channel display


Measured power, voltage and current values, integration values, with access to harmonic graphs and lists for each channel.





Wave+Noise display

Ideal for frequency analysis of inverter noise (FFT nalysis)



display efficiency and power loss

XY graph display

makes it easy to understand the motor I/O characteristics

Feed-through Current Sensor Enable Extremely Accurate Measurements

HIOKI's high-performance feed-through current sensors absolutely minimizes the effects of conductor position and external fields, making them exceptionally precise. Repeatability and stability are absolutely unmatched!












Feed-through current sensors meet a large variety of applications from electric or hybrid vehicle testing, inverter motor evaluations and solar power devices and fuel cell analysis to individual testing of electrical appliances and facilities equipment.

*For further information and specifications, please refer to page 15.







at 100ADC input, when measuring a 10mm diameter wire

Measure the primary and secondary sides of inverters

(Performance evaluation of motors and inverters)


Accurately and easily measure the power of inverters and motors for a wide range of applications, from research and development to field tests

Advantages

- 1. Isolated input of voltage and current lets you measure the power on the primary and secondary sides of inverters simultaneously.
- 2. Using a non-invasive current sensor makes the connection simple and easy. A vector diagram display ensures connections are checked.

Proprietary **HIOKI Technology**

- 3. Accurately measure the fundamental wave voltage and current values related to the motor axis output with confidence
- 4. All data is measured simultaneously and updated every 50 ms.
- 5. In addition to the harmonic analysis required to evaluate the inverter control, noise components can also be measured at the same time ideal for determining the leakage of inverter noise
- 6. Use of a current sensor reduces the effect of in-phase noise from inverters when measuring the power




PC measurements and synchronizing multiple devices

 Dedicated application software allows you to perform PC measurements right out of the box

LAN and USB compatibility facilitates efficient data collection and remote operation. Bundled application software allows you to control up to 4 units.

Acquire all data even when multi-unit measurements are performed.
 Two units can be connected using the CONNECTION CABLE 9683 (option) to synchronize the internal clocks and control signals.

Interval measurements with the two units allow the acquisition of perfectly synchronized data, making it easy to collect completely harmonized data with a CF card without using a PC.



■ What's so special about inverter motors?

Inverter motors are indispensable as the power source of industrial equipment. The rotation of an induction motor depends on the input frequency, so if this input frequency can be made variable, the rotation can be controlled freely. Development of a frequency conversion technology called an inverter has made it possible to freely control the rotation of motors.

In recent years, the mainstream inverter control method is the PWM (Pulse-width Modulation) method.

• What is the PWM method?


A pseudo sinusoidal waveform (fundamental wave) resulting from the conversion of the fundamental wave frequency that determines the rotation of a motor to a pulse train called a carrier frequency (at about several kHz to 15 kHz) is effected, controlling the number of rotations.

Performance evaluation and electrical measurement of motor

The axis output of a motor is closely related to the fundamental wave frequency to be input, so an accurate measurement of this fundamental wave component is required to evaluate the input characteristics.

Conventional measurement method

Traditional methods use the average rectified RMS indication (Mean) in order to obtain a component value close to the fundamental wave frequency from a pseudo sinusoidal waveform (fundamental wave + carrier wave) to be input. To measure an accurate fundamental component, frequency analysis was required; however, the conventional processing method was not practical because it could barely perform real-time measurements with FFT as a result of the limited computing power.



• The 3390 is capable of measuring the fundamental wave component accurately. The 3390 performs this frequency analysis using high-speed harmonic computation processing at an interval of 50 ms and displays the true fundamental wave component.

3 To make the best of inverter motor measurements:

· Parameters critical to the measurement of motor inputs (outputs on the secondary side of inverters) can be measured and displayed simultaneously.

Display item	Measurement details
rms value	RMS value of fundamental wave + carrier wave components
mn value	RMS value (mean value) close to the fundamental wave component
fnd value	True fundamental wave component
thd value	Displays the distortion factor of measured waveform
unb value	Displays the balance between phases
±pk value	Maximum positive/negative values of waveform that is being measured
dc value	Displays a DC component harmful to the motor
ac value	RMS value obtained by removing the DC component from the RMS value
f value	Frequency of each phase

4 Clearly display efficiency and loss of inverters

· Efficiency and loss measurement function built-in

The operating efficiency and power loss of an inverter can be displayed when measuring the inputs and outputs of the inverter simultaneously.



6 Harmonic measurement indispensable for inverter evaluation

 4-channel simultaneous harmonic analysis function built-in (Performed simultaneously with power measurement)

Harmonic analysis is essential for the development and evaluation of inverters Synchronized to the fundamental wave frequency from 0.5 Hz to 5 kHz Harmonic analysis up to the 100th order can be performed simultaneously with power measurement.



| MEAS | State | Chi | C

5 X-Y graph display lets you check the dynamic characteristics of inverters

• X-Y graph display function built-in (X-axis: 1 item, Y-axis: 2 items)


By simply specifying the voltage for the X-axis and the power consumption and efficiency for the Y-axis, you can display the dynamic characteristics of a motor in real time.



7 Evaluate of the troublesome noise of inverters

• Noise measurement function built-in (1-channel measurement: Performed simultaneously with power measurement and harmonic analysis)

Noise components at up to 100 kHz can be read while looking at the measured waveforms Simultaneously display the top 10 point frequency and voltage/current levels



8 Waveforms can be observed at 500 kS/s, and fundamental waves can also be checked

Waveform monitoring function fully supported

Display the voltage and current waveforms being measured

The carrier frequency components of an inverter are also displayed in real time

Filter function

A filter function is used to remove the carrier frequency components from the inverter, and fundamental wave frequency waveforms can be checked in the waveform display.

* The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.

| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.
| The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.

Geared for the latest motor evaluation and analysis of Hybrid Electric Vehicles, Electric Vehicles and the like


Drive the research and development of three-phase inverter motors with high accuracy and high-speed measurements

Advantages

- 1. Use of the MOTOR TESTING OPTION 9791 (9793) lets you perform a total evaluation of inverter motors
- 2. The voltage, torque, rotation, frequency, slip, and motor power required for motor analysis can be measured with one unit
- 3. Current sensors make the connection simple. In addition, use of the AC/DC CURRENT SENSOR enables measurements with superior accuracy

Proprietary HIOKI Technology


- 4. All data is measured simultaneously and updated every 50 ms. Data collection and characteristics tests can be performed at the industry's fastest speed
- 5. Evolution of electrical angle measurements critical to motor analysis has made it possible to perform more accurate measurements using an incremental encoder
- 6. Harmonic analysis at 0.5 Hz to 5 kHz without the need for an external timing mechanism
- 7. Built-in digital anti-aliasing filter (AAF) lets you measure the broadband power on the secondary side of inverters to make accurate harmonic analyses



1 Evaluate high-performance vector control inverters:

- Measurements of fundamental wave voltage and current and their phases based on an accurate harmonic analysis are indispensable to motor analysis
- Support of an incremental encoder allows detecting synchronization signals from a motor easily and accurately

Electrical angle measurements are indispensable for dynamic characteristics analysis of motors. The 3390 can conduct FFT analyses synchronized to rotation pulses from the tachometer and the motor induced voltage, and the A-phase and Z-phase pulse inputs that allow measuring and detecting the origin of the motor more simply and accurately – fully meeting the needs of the latest motor analysis tests.



Encoder Z-phase signal Oltage / current waveform

■ Application 1: "Electrical angle measurement"

- \circ The voltage / current fundamental wave component " θ " from the machine angle origin can be calculated by performing harmonic analysis of motor input voltage / current by synchronizing to the A-phase signal and z-phase signal of an encoder.
- A function to perform zero compensation for this phase angle when a motor induced voltage is generated can be used to measure the voltage and current phase (electrical angle) in real time based on the induced voltage when the motor is started.

■ The importance of measuring the electrical angle of synchronous motors

The key to the performance of high-performance low-fuel consumption vehicles represented by HEV and EV is the synchronous motor that is used as the power source. The synchronous motor is finely controlled by alternating signals generated by an inverter device (DC to AC conversion) using the electricity from batteries.

• What is a synchronous motor?

A synchronous motor rotates in synchronization with the AC frequency. Structurally, the motor is turned by the rotating force at the magnetic pole of the rotator (rotator magnetic pole), which is generated by the rotating magnetic field generated by applying an alternating current to the magnetic field (stator magnetic pole). The rotation speed is synchronized to the speed of the rotating magnetic field, so the

speed can be controlled by changing the speed of the rotating magnetic field (power supply frequency). In addition, high operating efficiency is one of the advantages of the synchronous motor.

• Why is electrical angle measurement necessary?

In the case of a synchronous motor, a phase shifting occurs between the stator magnetic pole and the rotator magnetic pole due to a change in the load torque. This shifted angle and the torque force that can be generated by a motor have a close relationship, so it is important to understand this shifted angle (electrical angle) in order to achieve high-efficiency motor control.

• The 3390 provides a more accurate measurement method

The 3390 supports the incremental encoder output in addition to the measurement methods of the HIOKI 3194 Power HiTESTER – enabling you to measure this electrical angle more easily and accurately.

2 Analyze harmonic signals from the low-speed rotation range of motors

• Harmonic analysis from a synchronization frequency of 0.5 Hz Accurate measurements can be performed in the low-speed rotation range of motors without the need of an external clock.

If the synchronization frequency is 45 Hz or more, analysis results are updated every 50 ms, so data analysis can be performed in real time.

Synchronization frequency range	Window wave number	Analysis order
0.5Hz to 40Hz	1	100th order
40Hz to 80Hz	1	100th order
80Hz to 160Hz	2	80th order
160Hz to 320Hz	4	40th order
320Hz to 640Hz	8	20th order
640Hz to 1.2kHz	16	10th order
1.2kHz to 2.5kHz	32	5th order
2.5kHz to 5.0kHz	64	3rd order

3 Vector display of electrical angles of motors


• Display vectors including that of the phase angle and electrical angle ($\varDelta\theta$) of fundamental wave voltage and current. The measured data can be used as parameters to calculate the Ld and Lq values.



5 X-Y graph display lets you check the dynamic characteristics of inverters

• X-Y graph display function built-in (X-axis: 1 item, Y-axis: 2 items)

By simply setting 2 items to the Y-axis as with a 6-axis graph used to evaluate motors, you can display the characteristics of a motor and similar devices in real time.



Analyze up to the 100th order

Synchronized to the fundamental wave frequency of 0.5 Hz to 5 kHz Simultaneously perform analysis up to the 100th order harmonic along with power measurement



4 Clearly view the inverter efficiency/loss and motor power

• Output, efficiency, and loss of inverter motors can be measured with one single unit


Operating efficiency and power loss of the inverter and motor can be displayed when the inputs and outputs of the inverter are measured simultaneously.



6 Simultaneously measure temperature that is indispensable for motor evaluation

• Connect the HIOKI 3440 Series Temperature HiTESTER to measure changes in the motor temperature and acquire data as parameters for motor evaluation


Connect the HIOKI 3440 Series Temperature HiTESTER to the 3390 (via the RS-232C interface) to acquire data while displaying the temperature.



■ Application 2: Electrical angle measurement using induced voltage of motors (The same measurements conducted with the HIOKI 3194 can also be performed)

Correct the rotation synchronization signal and induced voltage phase of motors as well as measure the phase of voltage and current for the induced voltage of a running motor as an electrical angle.

Step 1: Turn the motor from the load side, and measure the induced voltage of the motor




- \circ Measure the fundamental wave's RMS value and the total RMS value of the induced voltage.
- Perform zero compensation for the phase between the rotation synchronization signal and the fundamental wave voltage of the induced voltage.

Other Advance Functionsmotor

- Frequency divider circuit (up to 1/60000 frequency dividing) helpful when the rotation synchronization signal consists of multiple pulses for one cycle of induced voltage.
- • A-to-Y conversation function convert the line voltage to a phase voltage (virtual neutral reference) when three-phase three-wire (3P3W3M connection) measurements are performed.

Step 2: Measurement of a running motor



- Measure the fundamental wave component, harmonic component, and electrical angle of line voltage and current of a line to the motor. (The measured data can also be used as parameters for calculation of Lp/Lq)
- Simultaneously measure motor efficiency, inverter efficiency, total efficiency, and inverter loss while observing the motor control.

Evaluate new energies such as solar power, wind power, and fuel cells


Assess power conditioners that are indispensable for converting new energies to electrical power

Advantages

- 1. The input and output characteristics of a power conditioner can be measured simultaneously in combination with an AC/DC current sensor
- 2. Use of a current sensor makes the connection simple. Make accurate measurements in combination with the AC/DC CURRENT SENSOR
- 3. The sale and purchase of electrical energy of a power line connected to a power conditioner can also be measured with one unit

Proprietary HIOKI Technology

- 4. Measure DC mode integration, which responds quickly to changes in the input of sunlight and the like, and RMS mode integration, which handles the separate integration of the sale and purchase of electric energy, all at the same time
- 5. Ripple factor, efficiency and loss, which are required to evaluate power conditioners for solar power generation, can be measured with one single unit.



Conditioner-specific measurement items all measurable

 Power conditioner measurement-specific ripple factor and disequilibrium factor can also be measured and displayed simultaneously (up to 32 items can be displayed simultaneously), resulting in enhanced test efficiency

Display item	Measurement item
rms value	RMS (DC/AC voltage/current of input and output)
P, Q, S, λ values	Active power, reactive power, apparent power, power factor
Loss value	Input and output loss
η value	Efficiency
thd value	Distortion factor (voltage/current)
rf value	Ripple factor (for DC)
unb value	Disequilibrium
f value	Output frequency



■ Current trends in solar power generation

Interconnected system of solar power generation and power conditioner

Electrical energy generated from the solar power generation is DC electrical energy, so it needs to be converted to AC electrical energy to be used by connecting to the utility grid. The device to convert direct current to alternating current is the power conditioner. In particular, to sell electrical energy by connecting to the utility grid, the performance of the power conditioner is important, so the method to evaluate the performance is specified by the national standards.

IEC standard


IEC 61683:1999, Photovoltaic systems -Power conditioners- Procedure for measuring efficiency

Evaluation and measurement of power conditioners

The IEC standard stipulates detailed measurement items to evaluate the input and output characteristics of power conditioners such as harmonic level, ripple factor, voltage disequilibrium factor, and voltage/current waveform.

 The 3390 supports a long list of measurement items including the specific ones required.

The 3390 can measure ripple factor and evaluate and analyze through simultaneous measurements.



The efficiency (loss) and the amount of electrical energy sold and purchased can be displayed clearly

• Not only the amount of electricity generated with solar cells and the efficiency (loss) of a conditioner but also the amount of electrical energy sold and purchased by connecting to the utility grid can be measured simultaneously with one single unit



4 Accurately measure harmonics that are important for connecting to the utility grid

• The harmonic component and distortion factor important for connecting a power conditioner to the utility grid can be measured simultaneously.


Synchronized to the fundamental frequency of 0.5 Hz to 5 kHz.

Analyze up to the 100th order of voltage, current, and voltage harmonic, and display the current direction



3 Check the input and output waveforms of a conditioner

• Simultaneously check the input and output waveforms of a conditioner at 500 kS/s The input and output waveforms required to evaluate power conditioners can be checked simultaneously with one unit.



Also measure the noise flow of a connected utility grid

• Noise measurement function (1-channel measurement: Performed simultaneously with power measurement and harmonic analysis)

Noise components at up to 100 kHz can be read while looking at the measured waveforms Frequency and voltage/current levels for the top 10 points can be displayed simultaneously.




Bundled software dedicated to the 3390 (free download from the HIOKI website)

♦ Features

- Connect the **3390** to a PC via LAN or USB for completely remote operation
- Save measured data to the PC in real time (interval saving is also available)
- Download data stored in the USB memory or CF card
- Connect up to four 3390 Power Analyzers using the free software for remote operation and simultaneous data collection

Delivery media	Download from the HIOKI website
Operating	Windows 2000, XP, Vista, 7 PC
environment	Pentium III 500 MHz or higher CPU, 128 MB or more RAM, and LAN or USB interface
	Java Runtime Environment (JRE) 1.5.0 or later required
Communication	Ethernet (TCP/IP), USB 1.1/2.0
method	For a USB connection, use the supplied dedicated driver (included with the software)
Number of simultaneously- connected units	4
■ Functions	
Remote operation function	Key operation and screen display on a PC
Download function	Downloads data stored on the media (Files in the USB memory or CF card)
Display function	Displays instantaneously measured values of the 3390 on the PC monitor
	Numerical display: Basic measurement items
	Waveform display: Instantaneous waveform data
	Bar graph: Harmonic
	Vector: Fundamental wave vector
Measured value	Saves the specified instantaneous value data to the PC
save function	Selects the item to save from the numerical value display items in the display function
Interval save function	Saves instantaneous value data to the PC at the specified interval
CSV conversion function	Saves the displayed waveform data in CSV format to the PC
BMP save function	Saves the displayed waveform and graph data in image format to the PC or copy images to the clipboa
Setting function	Sends the settings of the 3390 made on a PC to the 3390
•	Setting contents can be saved and loaded to and from a file



■3390 Specifications
(Accuracy guarantee conditions: 23°C ±3°C, 80%RH or less, warm-up time 30 minutes or more, sinusoidal wave input, power factor 1, voltage to ground 0 V, in the range where the fundamental wave meets the conditions of the synchronization source after zero adjustment)

	ditions of the synchroniz	ation source a	rter zero adjustinent	.)
Input				
Measurement line	Single-phase two-wire (1P2W), single-phase three-wire (1P3W), the phase three-wire (3P3W2M, 3P3W3M), three-phase four-wire (3P4W)			
Connection setting	CH1	CH2	CH3	CH4
Pattern 1	1P2W	1P2W	1P2W	1P2W
Pattern 2	1P3W		1P2W	1P2W
Pattern 3	3P3W2M		1P2W	1P2W
Pattern 4	1P3W		1P3	3W
Pattern 5	3P3W2M		1P3	BW
Pattern 6	3P3W2M		3P3W2M	
Pattern 7	3	P3W3M	1P2W	
Pattern 8		3P4W		1P2W
Number of input channels	Voltage: 4 channels U1 Current: 4 channels I1 to	o I4	. 1)	
Input terminals	Voltage: Plug-in termina Current: Dedicated conf	nector		
Input method	Voltage: Isolated input, Current: Isolated input u			
Measurement range	(Selectable for each con			
Voltage range	15.000V / 30.000V / 60.00			
Current range	*400.00mA / *800.00mA			
() indicates the sensor rating used				
sensor rating used	1.0000A / 2.0000A / 5.0000A / 10.000A / 20.000A / 50.000A (50 A rating) 10.000A / 20.000A / 50.000A / 100.00A / 200.00A / 500.00A (500 A rating) * Only UNIVERSAL CLAMP ON CT 9277 is applicable			
Power range	Depends on combination of voltage and current range (6.0000 W to 2.2500 MW)			
Crest factor	3 (voltage/current), 1.33 for 1500 V			
Input method (50/60Hz)	Voltage input part: 2 M Ω ±40 k Ω (Differential input and isolated input) Current sensor input part: 1 M Ω ±50 k Ω			
Maximum input voltage	Voltage input part: 1500 V ±2000 V peak Current sensor input part: 5 V ±10 V peak			
Maximum rated voltage to ground	Voltage input terminal 1000 V (50/60 Hz) Measurement category III 600 V (Expected transient overvoltage 6000 V) Measurement category II 1000 V (Expected transient overvoltage 6000 V)			
Measurement method	Voltage and current simultaneous digital sampling and zero cross synchronization calculation method			
Sampling	500kHz / 16bit			
Frequency band	DC, 0.5 Hz to 150 kHz			
Synchronization frequency range	0.5Hz to 5kHz			
Synchronization source	U1 to U4 / I1 to I4 / Ext (with motor analysis option, CH B: when pulse is set) / DC (50 ms, 100 ms fixed) * Selectable for each connection (Zero cross auto follow-up by digital LPF when U / 1), Filter resistance two-stage switching (high / low), source input 30%f.s. or more when U / 1			
Data update rate	50ms			
LPF	OFF / 500 Hz / 5 kHz / 100 kHz (Selectable for each connection) When 500 Hz: Accuracy +0.1%f.s. specified at 60 Hz or less When 5 kHz: Accuracy specified at 500 Hz or less When 100 kHz: Accuracy specified at 20 kHz or less (1%rdg. is added at 10k Hz to 20 kHz)			
Polarity determination	Voltage/current zero cross timing comparison method			
Polarity determination Measurement parameters	Voltage (U), current (I), active power (P), apparent power (S), reactive power (Q), power factor (λ), phase angle (ϕ), frequency (f), efficiency (η), loss (Loss), voltage ripple factor (Ufr), current ripple factor (Ifr), current integration (Ih), power integration (WP), voltage peak (Upk), current peak (Ipk)			

Accurate	Voltage, currency,	and active power m	easurements
Accuracy			
	Voltage (U)	Current (I)	Active power (P)
DC	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
0.5Hz to 30Hz	±0.1%rdg.±0.2%f.s.	±0.1%rdg.±0.2%f.s.	±0.1%rdg.±0.2%f.s.
30Hz to 45Hz	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
45Hz to 66Hz	±0.05%rdg.±0.05%f.s.	±0.05%rdg.±0.05%f.s.	±0.05%rdg.±0.05%f.s.
66Hz to 1kHz	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
1kHz to 10kHz	±0.2%rdg.±0.1%f.s.	±0.2%rdg.±0.1%f.s.	±0.2%rdg.±0.1%f.s.
10kHz to 50kHz	±0.3%rdg.±0.2%f.s.	±0.3%rdg.±0.2%f.s.	±0.4%rdg.±0.3%f.s.
50kHz to 100kHz	±1.0%rdg.±0.3%f.s.	±1.0%rdg.±0.3%f.s.	±1.5%rdg.±0.5%f.s.
100kHz to 150kHz	±20%f.s.	±20%f.s.	±20%f.s.
	* Voltage and active power values * Voltage and active power values * Voltage and active power values * Voltage and active power values	wer values at 0.5 Hz to 10 Hz are refi more than 220 V at 10 Hz to 16 Hz z more than 750 V at 30 kHz to 100 ki more than (22000/f [kHz]) V at 100 ki more than 1000 V are reference value ver values, add the accuracy of the ct	are reference values Hz are reference values Hz to 150 kHz are reference values es
Accuracy guarantee period	6 months (One-year accuracy is the above accuracy x 1.5)		
Temperature coefficient	±0.01%.f.s / °C (When DC: Add ±0.01%f.s./°C)		
Effect of common mode voltage	±0.01%f.s. or less (When input terminal and the ca	n applying 1000 V (50/60 se)	Hz) between the voltage
Effect of external magnetic field	±1.0%f.s. or less (in a ma	agnetic field at 400 A/m, D	C, and 50/60 Hz)

Effect of power factor	$\pm 0.15\% f.s.$ or less (When power factor = 0.0 at 45 Hz to 66 Hz), add $\pm 0.45\% f.s.$ when LPF is 500 Hz
Effective measurement range	Voltage, current, and power: 1% to 110% of range
Display range	Voltage, current, and power: Range's zero suppress range setting to ±120%
Zero suppress range	Selects from OFF, 0.1%f.s., and 0.5%f.s. * When OFF is selected, a numerical value may be displayed even if zero is input
Zero adjustment	Voltage: ±10%f.s. Current: ±10%f.s. zero correction is performed for an input offset less than ±4 mV
Waveform peak measurement	Range: Within ±300% of respective voltage and current range Accuracy: Voltage and current respective display accuracy ±2%f.s.

Frequency n	neasurement
Number of measurement channels	4 channels (f1, f2, f3, f4)
Measurement source	Selects from U / I for each input channel
Measurement method	Reciprocal method + zero cross sampling value correction
Measurement range	Within synchronization frequency range between 0.5 Hz and 5 kHz
Data update rate	50 ms (Depends on the frequency when 45 Hz or less)
Accuracy	±0.05%rdg.±1dgt. (When sinusoidal waveform is 30% or more relative to the measurement range of measurement source)
Display range	0.5000Hz to 9.9999Hz / 9.900Hz to 99.999Hz / 99.00Hz to 999.99Hz / 0.9900kHz to 5.0000kHz

Integration r	neasurement
Measurement mode	RMS / DC (Selectable for each connection, DC is only available when AC/DC sensor is used for IP2W connections) RMS: Integrates the current RMS values and active power values, only the active values are integrated for each polarity DC: Integrates the current values and instantaneous power values for each polarity
Measurement item	Current integration (Ih+, Ih-, Ih), active power integration (WP+, WP-, WP) Ih+ and Ih- are available only in DC mode, and only Ih is available in RMS mode.
Measurement method	Digital calculation from each current and active power
Measurement interval	Data update rate of 50 ms
Display resolution	999999 (6 digits + decimal point)
Measurement range	0 to ±9999.99 TAh / TWh (Integration time is within 9999 h 59 m) If any integration value or integration time exceeds the above limit, integration stops.
Integration time accuracy	±50 ppm ±1 dgt. (0°C to 40°C)
Integration accuracy	±(Accuracy of current and active power) ± integration time accuracy
Backup function	If power fails during integration, integration resumes after power is restored

Harmonic m			
Integration time accuracy	4 channels (Harmonic measurement for another line at a different frequency cannot be performed)		
Measurement item	Harmonic voltage RMS value, harmonic voltage percentage, harmonic voltage phase angle, harmonic current RMS value, harmonic current percentage, harmonic current phase angle, harmonic active power, harmonic power percentage, harmonic voltage/current phase difference, total harmonic voltage distortion factor, total harmonic current distortion factor, voltage disequilibrium factor, current disequilibrium factor		
Measurement method	Zero cross synchronous cal	culation method (All chann	nels same window) with gap
Synchronization source	U1 to U4 / I1 to I4 / Ext (Mo DC (50 ms/100 ms)	otor analysis option included	d, CHB: when pulse is set) /
FFT processing word length	32-bit		
Anti-aliasing filter	Digital filter (Variable by	the synchronization freq	uency)
Window function	Rectangular		
Synchronization frequency range	0.5 Hz to 5 kHz		
Data update rate	50 ms (Depends on the sy	ynchronization frequency	when less than 45 Hz)
Phase zero adjustment	Phase zero adjustment is possible by key / communication command (only when the synchronization source is Ext)		
	Synchronization frequency range	Window wave number	Analysis order
	0.5Hz to 40Hz	1	100th order
Maximum analysis order	40Hz to 80Hz	1	100th order
	80Hz to 160Hz	2	80th order
	160Hz to 320Hz	4	40th order
	320Hz to 640Hz	8	20th order
	640Hz to 1.2kHz	16	10th order
	1.2kHz to 2.5kHz	32	5th order
	2.5kHz to 5.0kHz	64	3rd order

	F	Voltage (LD) / suggest (D) / setting a suggest (D)	
	Frequency 0.5Hz to 30Hz	Voltage (U) / current (I) / active power(P) ±0.4%rdg.±0.2%f.s.	
	30Hz to 400Hz	±0.4%rdg.±0.2%rls. ±0.3%rdg.±0.1%f.s.	
	400Hz to 1kHz	±0.3%rdg.±0.1%r.s. ±0.4%rdg.±0.2%f.s.	
Accuracy	1kHz to 5kHz	±1.0%rdg.±0.5%f.s.	
	5kHz to 10kHz	±2.0%rdg.±1.0%f.s.	
	10kHz to 13kHz	±5.0%rdg.±1.0%f.s.	
		en the synchronization frequency is 4.3 kHz or more	
Noise measu	urement (FFT proces	1 1	
Number of channels	1 channel (Selects one chann	nel from CH1 to CH4)	
Measurement item	Voltage/current		
Calculation type	RMS spectrum		
Measurement method	500 kHz/s sampling (Decima	ation after digital anti-aliasing filtering)	
FFT processing word length	32-bit	/10,000	
Number of FFT points	waveform display record len		
		by the maximum analysis frequency)	
Window function	0 0	*	
Data update rate	Within about 400 ms to 15 s do	epending on the number of FFT points, with gap	
Maximum analysis frequency	100kHz / 50kHz / 20kHz / 10		
Frequency resolution	0.2 Hz to 500 Hz (Determ maximum analysis frequency	nined by the number of FFT points and the y)	
Noise value measurement	Calculates the levels and (maximum values) for the to	frequencies of voltage and current peak p 10 points	
MOTOR TES	TING OPTION (App	licable to the 9791 and 9793)	
	3 channels		
Number of input channels	CH A: Analog DC input / frequency input (torque signal input) CH B: Analog DC input / pulse input (rotation signal input) CH Z: Pulse input (Z-phase signal input)		
Input terminal form	Isolation type BNC connected		
Input resistance (DC)	1 M Ω±100 kΩ	*	
Input method	Isolated input and differentia	al input (No isolation between CH B and CH Z	
Measurement item			
Maximum input voltage	±20 V (When analog / freque	ency / pulse)	
Maximum rated voltage to ground		ement category I 50 V (Expected transien	
Accuracy guarantee period	6 months (One-year accuracy	y is the accuracy below x 1.5)	
	out (CH A / CH B)		
Measurement range		analog DC input)	
Effective input range			
Sampling Measurement	10 kHz / 16-bit Simultaneous digital sampli	ing and zero cross synchronization calculation	
method	method (zero cross averaging	g)	
Synchronization source	Same as the 3390 power measurement input specification (Common for CH A		
Accuracy	and CH B) ±0.1%rdg. ±0.1%f.s.		
Temperature coefficient	±0.1%rdg. ±0.1%l.s. ±0.03%f.s./°C		
Effect of common			
mode voltage	terminal and the 3390 case Range's zero suppress range setting to ±120%		
Display range Zero adjustment	Range's zero suppress range setting to ±120% Voltage ±10%f.s.		
	out (only for CH A)		
Effective			
amplitude range	±5Vpeak		
Measurement range	100kHz		
Band width	1kHz to 100kHz		
Accuracy	±0.05%rdg.±3dgt.		
Display range	1.000kHz to 99.999kHz		
3. Pulse input (c			
Detection level	Low: 0.5 V or less, High: 2.0		
Maria de la compansión	1 Hz to 200 kHz (When duty		

Measurement band 1 Hz to 200 kHz (When duty ratio is 50%)

 $2.5~\mu s$ or more

Detection level Low: 0.5 V or less, High: 2.0 V or more

frequency range pulse is divided by the set frequency dividing number)

D/A OUTPUT OPTION (Applicable to the 9792 and 9793)

0.5 Hz to 5.0 kHz (Specified by the frequency at which the measurement

OFF / ON (When ON, a frequency divider circuit of CH B is cleared by a rising edge)

Frequency divider 1 to 60000

Accuracy ±0.05%rdg. ±3dgt.
4. Pulse input (only for CH Z)

Measurement band 0.1 Hz to 1 kHz

Number of output 16 channels

setting range

Measurement

detection width

Minimum detection width Setting

channels

Minimum

Accuracy

Output content	Switchable between Waveform output / Analog output (selects from the measurement items) * Waveform output is only for CH 1 to CH 8
Output terminal form	D-sub 25-pin connector × 1
D/A conversion resolution	16-bit (Polarity + 15-bit)
Output voltage	Analog: DC ±5 Vf.s. (Max. about DC ±12V) Waveform output: 2 Vrms f.s., crest factor: 2.5 or more
Accuracy	Analog output: Measurement accuracy $\pm 0.2\%$ f.s. (DC level) Waveform output: Measurement accuracy $\pm 0.5\%$ f.s. (at RMS level, in synchronization frequency range)
Accuracy guarantee period	6 months (one-year accuracy is the above accuracy × 1.5)
Output update rate	Analog output: 50 ms (As per the data update rate of the selected item) Waveform output: 500 kHz
Output resistance	100 Ω ±5 Ω
Temperature coefficient	±0.05%f.s./°C
Display	
	English / Japanese / Chinese (simplified characters)
Display	9-inch TFT color LCD display (800 × 480 pixels)
LCD backlight Display resolution	ON / Auto OFF (1min / 5min / 10min / 30mim / 60min) 99999 counts (Integrated value: 999999 counts)
Display refresh rate	200 ms (Independent of internal data undate rate: waveform and FET
Display screen	Measurement, Setting, File Manipulation screens
External inte	erfaces
1. USB Interface	
Connector	Series Mini-B receptacle
Electrical	USB2.0 (Full Speed / High Speed)
specification Number of ports	1
Class	Vendor specific (USB488h)
Destination	PC (Windows 2000 / XP / Vista (32-bit version))
Function	Data transfer, remote operation, command control
2. USB memory Connector	USB type A connector
Electrical	
specification	USB2.0
Power supply	Up to 500 mA
Number of ports Applicable USB	USB Mass Storage Class
Recordable items	Setting file: Save/Load Measured value/recorded data: Copy (from the CF card data)
0.1.401	Waveform data: Save, screen hard copy
3. LAN interface Connector	RJ-45 connector × 1
Electrical	
specification	IEEE802.3 compliant
Transmission method	10BASE-T / 100BASE-TX auto recognition
Protocol	TCP/IP
Function	HTTP server (remote operation), dedicated port (port transfer, command control)
4. CF card inter	TYPE I x 1
Usable card	Compact flash memory card (32 MB or more)
Applicable	Up to 2 GB
memory capacity Data format	•
	MS-DOS format (FAT16 / FAT32) Setting file: Save / Load
Recordable items	Measured value / automatically recorded data: Save (in CSV format) Waveform data: Save, screen hard copy
5. RS-232C inter	rface
Method	RS-232C, EIA RS-232D, CCITT V.24, JIS X5101 compliant
Connector Destination	D-sub 9-pin connector × 1 thermometer
	Full duplex asynchronous method
Recordable items	Data length: 8, parity: none, stop bit: 1, Flow control: Hard flow, delimiter: CR+LF
	1 low control. Hard now, definition. CR 1 L1
Baud rate	2400, 9600, 19200, 38400 bps (2400 bps for thermometer)
6. Synchronizat	2400, 9600, 19200, 38400 bps (2400 bps for thermometer) ion control interface
6. Synchronizat Terminal form	2400, 9600, 19200, 38400 bps (2400 bps for thermometer) ion control interface IN-side 9-pin round connector x 1
6. Synchronizat Terminal form Signal	2400, 9600, 19200, 38400 bps (2400 bps for thermometer) ion control interface IN-side 9-pin round connector ×1, OUT-side 8-pin round connector x 1 5 V (CMOS level)
6. Synchronizat Terminal form	2400, 9600, 19200, 38400 bps (2400 bps for thermometer) ion control interface IN-side 9-pin round connector x 1

allowable lilput					
Signal delay Up to 2 µs (Specified by the rising edge)					
Functions					
1. Setting					
Rectification switching	rms / mean (Selectable for the voltage/current of each connection) rms: Displays the true RMS value (True RMS) mean: Displays the average-value rectified RMS value				
	1 7 5				
Auto range	OFF / ON (Voltage and current range is selectable for each connection)				

Soms (When 200 ms; 520) 40 About 2 days About 2 days 18 2600 10 About 2 days 10 About 2 10 10 10 10 10 10 10							
* Maximum number of items to save can be specified by the setting (130 items/50 item						s / 15 s / 30	s /
Interval time and maximum number Auto-save of tems to be saved Interval time and maximum number Auto-save of tems to be saved Interval time and maximum number Auto-save of tems to be saved Interval time and maximum number Auto-save of tems to be saved Interval time to the saved Interval time About 2 days About 1 hours About 2 days About 1 hours About 2 days About 1 hours About 1 hours							
of lems to be saved interval when using a 512 MB card) interval interval interval when some properties in the control of the c							
of lems to be saved interval when using a 512 MB card) interval interval interval when some properties in the control of the c		Interval time a	ınd maximum nı	umber Auto	-save		
Soms 130 10 About 2 days 150 About 2 days 150 150 About 2 days 150 150 About 4 days 150 150 About 4 days 150 150 About 4 days About 4 days About 4 days About 4 days About 7 days Abou							
Soms (When 200 ms 520) 40 About 14 hours 15 C sor more: 5000 100 About 14 hours 16 C sor more: 5000 100 About 14 hours 16 About 7 days 16 About 7 days 16 About 7 days 17 About 7 days 17 About 7 days 18 About 7 days 1	Data save	Interval		ems Number			
1s	Interval	50ms		520)		1	
18 (5 s or more: 5000) 1000 About 11 hours 1min 5000 40 About 416 days 400 About 416 days 400 About 7 days 4				520)			
Imin 5000 40 About 7 days OFF / Timer / Actual time When using Actual Time: 10 s to 9999 h 59 m 59 s (unit: 1 min) Vertaging OFT / Tatio: OFF / 0.01 to 99999 99 CT ratio: OFF / 0.01 to 99999 99 CT ratio: OFF / 0.01 to 99999 99 Displays the averaged values of all instantaneously measured values including harmonic value (Excluding the peak value, integrated value, and noise value) Averaged data applies to all data including the saved data during averaging (Excluding the peak value, integrated value, and noise value) Averaged data applies to all data including the saved data during averaging (Applies to the data update rate of 50 ms) Response time Exponential averaging (Applies to the data update rate of 50 ms) Galculated item of the company of the co		1s		000)			
me control OFF / Timer / Actual time OFF / Timer / Actual time OFF / Timer / Actual time When using Actual Time: Start time / stop time (unit: 1 min) VT ratio: OFF / Dol 10 s9999.99 Carlouding the peak value, integrated value, and noise value (Excluding the peak value, integrated value, and noise value) *Averaged data applies to all data including the saved data during averaging Exponential averaging (Applies to the data update rate of 50 ms) Response time OFF / 0.2s (FAST) / 1.0s (MID) / 5.0s (SLOW) (Time within which off bill in the accuracy range when the imput changes to \(\frac{1}{2} \) s. to connection and channel. Calculated item Active power value (P) for each channel and connection Active power value (P) for each channel and connection whose power for whose the year of a calculation trate **The latest data of calculation is used for a calculation between connections and beas synchronization sources are different Calculation Calculation algorithm To Calculation Calculation algorithm **To Calculation algorithm To Calculation algorithm algorithm algorithm algorithm algorithm algorithm algorithm algorithm algorithm a			`	000)			
When using Timer: 10 s to 9999 h 59 m 59 s (unit: 1 s) When using Caula Time: Start time / stop time (unit: 1 min) VT ratio: OFF / 0.01 to 9999 .99 CT ratio: OFF / 0.01 to 9999 .99 (Excluding the peak value, integrated value, and noise value) Averaged data applies to all data including the saved data during averaging Applies to the data update rate of 50 ms) OFF / 0.2s (FAST) / 1.0s (MID) / 5.0s (SLOW) Glaculation and Exponential averaging (Applies to the data update rate of 50 ms) OFF / 0.2s (FAST) / 1.0s (MID) / 5.0s (SLOW) Glaculation rate Calculated time Active power value (P) for each channel and connection Motor power (Pm) when the 9791 and 9793 Motor Analysis Option is included Calculation rate Calculated starts of calculation is used for a calculation between connections whose synchronization sources are different Calculation algorithm Calculated item is specified for Pm and Pout in the format below yiellow (P) (Pipm), Losse [Pm]. Pout] Converts line voltage waveform to phase voltage waveform using the virtual neutral point for 379W 3M connection Control and the neutral point for 379W 3M connection Output data DA output data DA output (P) data save: Outputs the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected DA output data DA output (P) data save: Outputs the hold data (Phe waveform output continues and the interval and t		1min					
When using Actual Time: Start time / stop time (unit: 1 min) VT ratio: OFF / 0.01 to 9999.99 CT ratio: OFF / 0.01 to 9999.99 CT ratio: OFF / 0.01 to 9999.99 Displays the averaged values of all instantaneously measured values including harmonic value (Excluding the peak value, integrated value, and noise value) Averaged data applies to all data including the saved data during averaging Averaged data applies to all data including the saved data during averaging Calculated item Calculated item Calculated item Calculates the efficiency ry [%] and loss [W] of active power for each connection and channel. Calculated item Calculation rate Calculated and channel. Calculated item so see of the control of the connection when the open of the connection of t		OFF / Timer / A	Actual time				
Content Cont	Time control						
reraging CT ratio: OFF / 0.01 to 9999.99					ime (unit:	l min)	
harmonic value (Excluding the peak value, integrated value, and noise value) Averaged data applies to all data including the saved data during averaging Exponential averaging (Applies to the data update rate of 50 ms) Response time OPF / 0.2 (REXT) / 1.0s (MID) / 5.0s (SLOW) (Ime within which to fall in the accuracy range when the imput changes to 8% s. to 100% s.) (Calculated item Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Active power value (P) for each channel and connection Calculated in the security of the connection of the security of the security of the connections whose synchronization sucress are different Calculated in the security of the securi	Scaling						
Excluding the peak value, integrated value, and noise value)	Averaging			f all instantan	eously meas	sured values	including
## Averaged data applies to all data including the saved data during averaging Exponential averaging (Applies to the data update rate of 50 ms) Response time OFF /0.2s (FAST) / 1.0s (MID) / 5.0s (SLOW) (Time within which to fall in the accuracy range when the input changes to 0%f.s. to 100%f.s. to 100%				grated value.	and noise v	alue)	
Response time OFF (0.2s (FAST) / 1.0s (MID) / 5.0s (SLOW) Calculated with which to fall in the accuracy range when the input changes to 0%4.s. to 100%4.s. to 10							eraging
(Time within which to fall in the accuracy range when the input changes to 0%f.s. to 100%f.s.) (Iculation Calculates the efficiency \(\pi \) and loss \(\mathbb{W} \) of active power for each connection and channel. Active power value \(\pi \) for each channel and connection Motor power value \(\pi \) when the 973 and 9793 Motor Analysis Option is included Calculation rate Calculates and updates at a data update rate of 50 ms * The latest data of calculation is used for a calculation between connections whose synchronization sources are different connections whose synchronization sources are different connections whose synchronization sources are different value in the format below \(\pi = \text{100X} \) [Pout] \(\pi \) [Pin \(\pi \) Loss= \[\pi \) [Pin \(\pi \) [Pout] \(\pi \) [Pin \(\pi \)						of 50 ms)	
Calculates the efficiency \(\pi \) and loss \(\mathbb{N} \) of active power for each connection and channel. Calculation rate Active power value \(\mathbb{P} \) for each channel and connection Motor power \(\mathbb{P} \) mother the \(\mathbb{P} \) and \(\mathbb{P} \) and \(\mathbb{P} \) so \(\mathbb{P} \) and \(Response time					nges to 0%fs to	o 100%fs)
Calculated item	Efficiency/loss	-					
Motor power (Pm) when the 9791 and 9793 Motor Analysis Option is included Calculation rate The latest data of calculation is used for a calculation between connections whose synchronization sources are different 3 formats for the efficiency and loss, respectively	calculation	connection and	l channel.				
Calculation rate Calculates and updates at a data update rate of 50 ms * The latest data of calculation is used for a calculation between connections whose synchronization sources are different connections whose synchronization sources are different parameters. Calculated item is specified for Pin and Pout in the format below n=100X [Pout] / [Pin], Loss= [Pin] - [Pout] Converts line voltage waveform to phase voltage waveform using the virtual neutral point for 3P3W3M connection Uses a phase voltage to calculate all voltage parameters including harmonic or voltage RMS value Stops and displays all displayed measured values and display update of waveforms Updates data when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected D/A output. CF data save: Outputs the hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is updated) Data update Data update Data update Data update Data update Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) Output data Output data Output data Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) Displays Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) Displays because of case and update rate of 50 ms) Displays and internal data update rate of 50 ms) Displays and updates the reached of 30 ms) Displays has the connection diagram and the voltage/current vector diagram with the vector diagram of the values are displayed for each measurement in pattern of combined connections and exceed of the substance of the substance of the substance	Calculated item					Ontion is incl	luded
*The latest data of calculation is used for a calculation between connections whose synchronization sources are different and connections whose synchronization sources are different and connections whose synchronization sources are different specifically and the property of the propert	Calculation rate					Option is file	luucu
Calculable factors 3 formats for the efficiency and loss, respectively	, and and rate	* The latest	data of calcul	lation is use	ed for a c		between
Calculated item is specified for Pin and Pout in the format below	Coloulable forts					nt	
n=100X Pout / Pin , Loss= Pin - Pout Converts line voltage waveform to phase voltage waveform using the virtual neutral point for 3P3W3M connection Uses a phase voltage to calculate all voltage parameters including harmonic or voltage RMS value Stops and displays all displayed measured values and display update of waveforms Data update Output data D/A output, CF data save: Outputs the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected Output data D/A output, CF data save: Outputs the hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is updated) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data update Output data Output data Output data Output data Output data The value are averaging. This cannot be used in conjunction with the Hold function) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Displays Displays the connection diagram and the voltage/current vector diagram *The right connection range is displayed in the vector diagram, so the connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen Basic Measurement screen, Nover Measurement screen Basic Measurement screen, Nover Measurement screen Bar Graph screen, List screen, Vector screen Belect/Display Bar Graph screen, List screen, Vector screen Belect/Display between the server of the pattern of combined connections Bar Graph screen, List screen, Vector screen Belect/Display the numerical values of efficient and loss set in the calculation algorithm Displays the voltage/current waveforms ampled at 500 kHz in a compressed screen *Displays the waveform and						mat helow	
Splay hold Data update Output data Data update Output data Data update Output data Data update Output data Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured values and display and data (without waveform display and integrated value) Output data Data update Output data Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured values after averaging. This cannot be used in conjunction with the Hold function) Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) Di/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Displays Displays the connection diagram and the voltage/current vector diagram and the voltage/current vector diagram are manufactured by the real part of the values on channels I to 4 * The values are displayed for each measurement line pattern of combined connections are displayed and the vector diagram, so the connection and be checked. Displays measured power and harmonic values on channels I to 4 * The values are displayed for each measurement line pattern of combined connections are displayed and the vector screen. Bar Graph screen, List screen, Vector screen Bar Graph screen, List screen, Vector screen Bar Graph screen, List screen, Vector screen Display pattern: 3 efficiency items, 3 loss items. Display pattern: 3 efficiency items, 3 loss items. Displays the unwerform and noise measurement (FFT calculation) result when noise measurement screen Paceording speed 1,000 points / 5,000 points / 5,	Salcalation algorithm				it in the for	mat ociow	
Uses a phase voltage to calculate all voltage parameters including harmonic or voltage RMS value Stops and displays all displayed measured values and display update of waveforms Updates data when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected D/A output, CF data save: Outputs data immediately before it is updated) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured value after averaging is performed, the maximum value is applied to the measured to a complex of the measured of the measured to a complex of the measured of the measured to a complex of the measured of the measured of the measured is a pudated at an internal data update rate of 50 ms) Displays the connection diagram and the voltage/current vector diagram so the connections and the saurement screen. Power Measurement screen. Power Measurement screen. Select Displays measured power and harmonic values on channels 1 to 4 The values are displays any 4, 8, 16, or 32 measurement screen, Current Measurement screen, Power Measurement screen. Selects and displays and the selection and loss set in the calculation algorithm Display pattern:						waveform u	ising the
or voltage RMS value Stops and displays all displayed measured values and display update of waveforms to pate update Output data D/A output, CF data save: Outputs the hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is updated) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data update Output data Output data Output data Output data Output data The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Displays before it is cleared) Displays the connection diagram and the voltage/current vector diagram ammonic screen Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement line pattern of combined connections Bar Graph screen, List screen, Vector screen Belect/Display Treen Bar Graph screen, List screen, Vector screen Belect/Display bisplays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation result when noise measurement is performed Trigger Record Length Trigger Trigger Record Length Tr	△ – Y calculation					e including	harmonic
Data update Output data D/A output, CF data save: Outputs the hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is updated) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data update Data update Data update Data update Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Displays onnection Bolisplays the connection diagram and the voltage/current vector diagram and the sacreman so the connection can be checked. Displays the connection range is displayed in the vector diagram, so the connection can be checked. Basic Measurement screen, Power Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation result when noise measurement is performed Trigger Record Length Trigger Record Length Recording speed/ Recording speed/ Recording speed/ Recording speed/ Recording length Recording speed/ Recording speed/ Recording speed/ Recording speed/ Recording speed/ Recording speed/ Recording				ate all voltage	e parameter	s including i	namionic
Output data Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) Output data Data update Output data Outp	Display hold			neasured values	and display	update of way	veforms
Output data and the interval auto-save outputs data immediately before it is updated.) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display screen Displays the connection diagram and the voltage/current vector diagram *The right connection diagram and the voltage/current vector diagram *The right connection gains displayed in the vector diagram, so the connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen, Current Measurement screen, Power Measurement items from all basic measurement items Basic Measurement screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 4 fitems, 8 items, 16 items, or 32 items (4 pattern switching) Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source 1,000 points / 5,000 points / 10,000 points x all voltage/current channels tooks/s 250kS/s 2ms 10ms 20ms 100ms 250kS/s 10ms 20ms 100ms 250kS/s 10ms 20ms 10ms	Data update						terval is
and the interval auto-save outputs data immediately before it is updated.) Displays and updates the maximum value for each of all measured data (without waveform display and integrated value) (While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display before it is a cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display before it is cleared) Displays the connection diagram and the voltage/current vector diagram. *The right connection rage is displayed in the vector diagram, so the connection can be checked. Displays steme as displayed for each measurement line pattern of combined connections Basic Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Belect/Display Displays pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) brigaly pattern: 3 efficiency items, 3 loss items. Display pattern: 3 efficiency items, 3 loss items. Displays the numerical values of efficient and loss set in the calculation algorithm brigate pattern is efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the numerical values of efficient and loss set in the calculation result when noise measurement is performed From the pattern synthesis of the pattern	Output data						continues
Data update Data update Output data Output data Output data Output data Display Displays the connection display and integrated value) Displays measured power and harmonic values on channels I to 4 *The values are displayed for each measurement line pattern of combined connections are menoric screen Bar Graph screen, List screen, Voltage Measurement screen, Current Measurement screen Bar Graph screen, List screen, Voltage Measurement items pisplays the voltage/current weetform all basic measurement items Displays the workform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source Trigger Record Length Compression Ratio Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source 1.000 points / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels fooks/s 2ms 10ms 20ms 100ms 250kS/s 2ms 10ms 20ms 100ms 200ms 1000ms 250kS/s 2ms 10ms 20ms 1000ms 200ms 1000ms 250kS/s 10ms 50ms 100ms 500ms 1000ms 5000ms 10kS/s 10ms 50ms 100ms 5000ms 10kS/s 10ms 50ms 1000ms 5000ms 10kS/s 10ms 500ms 1000ms 5000ms 10kS/s 10ms 500ms 1000ms 5000ms 10kS/s 10ms 500ms 1000ms 256kS/s 4ms 20ms 40ms 2000ms 10kS/s 10ms 50ms 1000ms 5000ms 50kS/s 2ms 10ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 10ms 50ms 1000ms 5000ms 10kS/s 10ks and the data update rate, data is not recorded, and drawing data is cleared value after a variety and the vertical axes from the basic measurement items and displays them in the X-Y graph 4 horizontal axis: 1 item (with gauge display)	Output data						continues,
While averaging is performed, the maximum value is applied to the measured value after averaging. This cannot be used in conjunction with the Hold function) Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display before it is cleared) Displays the connection diagram and the voltage/current vector diagram and splay screen MM screen Displays measured power and harmonic values on channels 1 to 4 *The values are displayed for each measurement line pattern of combined connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Belect/Display reen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen bisplay pattern: 3 efficiency items, 3 loss items. Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen according time Record Length Dompression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length Fecording length Trigger Record Length Dompression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length The repair is drawn at the data update rate, data is not recorded, and drawing data is cleared option. Provided the provided in the vector diagram, so the connection and displays them in the X-Y graph The graph is drawn at the data update rate, data is not recorded, and drawing data is	Peak hold				each of all 1	neasured data	a (without
value after averaging. This cannot be used in conjunction with the Hold function) Data is cleared when the hold key is manipulated, when the interval is reached, and when an external synchronization signal is detected (Data is updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display connection neck screen Onnection splay screen Displays the connection diagram and the voltage/current vector diagram and the vector diagram, so the connection can be checked. Displays measured power and harmonic values on channels I to 4 *The values are displayed for each measurement line pattern of combined connections MM screen Basic Measurement screen, Voltage Measurement screen, Current Measurement screen Measurement screen Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current synchronization source Indicate the calculation of points					ı value is ar	onlied to the	measured
Output data Output data Output data Tribright connection splay screen Basic Measurement screen, Power Measurement items from all basic measurement screen Bar Graph screen, List screen, Vector screen Belect/Display streen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement screen Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen Trigger Record Length Trigger Record Length Compression Ratio Brooks/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 100ms 200ms 10kS/s 10ms 500ms 1000ms 5000ms Py Plot screen Option Totsplay is detected (Data is updated at a internal data update rate of 50 ms) DiA output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Displays the connection diagram and the voltage/current vector diagram, so the connection can be checked. Displays measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement screen Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen Pisplays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Record Length 1,000 points / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels to the proposal point of the proposal poi							
updated at an internal data update rate of 50 ms) D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display Display Display to connection Bolay screen The right connection diagram and the voltage/current vector diagram The right connection range is displayed in the vector diagram, so the connection can be checked. The values are displayed for each measurement line pattern of combined connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen Posplays the vaveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Trigger Record Length Dopoints / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length Recording length 1,000 points 5,000 points 10,000 points 10,000 points 50,000 points	Data update						
Output data D/A output, CF data save: Outputs the peak hold data (The waveform output continues, and the interval auto-save outputs data immediately before it is cleared) Display Display Display the connection diagram and the voltage/current vector diagram The right connection range is displayed in the vector diagram, so the connection can be checked. Displays measured power and harmonic values on channels 1 to 4 The values are displayed for each measurement line pattern of combined connections MM screen Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm bisplay pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen Trigger Record Length Tompression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length Trigger Synchronization timing of harmonic synchronization source 1,000 points / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels follows/s Tompression Ratio Trigger Recording length Trigger Recording speed / Recording length Trigger Record Length Trigger Trigger Record Length Trigger Record Length Trigger Trigger Record Length Trigger						is detected	(Data is
immediately before it is cleared) Display Display the connection diagram and the voltage/current vector diagram *The right connection range is displayed in the vector diagram, so the connection can be checked. Displays measured power and harmonic values on channels I to 4 *The values are displayed for each measurement line pattern of combined connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Recording length 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length Fecording length 1/000 points / 5,000 points / 5,000 points / 10,000 points / 50,000	Output data	_					
Display ponnection neck screen The right connection diagram and the voltage/current vector diagram, so the connection can be checked. Displays measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source 1,000 points / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording speed / Recording speed / Recording length 1,000 points 5,000 points 10,000 points 50,000					interval au	ito-save out	puts data
Displays the connection diagram and the voltage/current vector diagram *The right connection diagram and the voltage/current vector diagram *The right connection range is displayed in the vector diagram, so the connection can be checked. Displays measured power and harmonic values on channels 1 to 4 *The values are displayed for each measurement line pattern of combined connections Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source 1,000 points /5,000 points /10,000 points /50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording speed/ Recording length Recording length 1,000 points 5,000 points 10,000 points 50,000 points 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 500ms 50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Y Plot screen Option Horizontal axis: 1 item (with gauge display)	2 Display	immediately be	efore it is cleare	d)			
Displays measured power and harmonic values on channels 1 to 4 *The values are displayed for each measurement line pattern of combined connections MM screen Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Possplays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the vaveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Compression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording time Recording speed / Recording length 1,000 points / 5,000 points / 10,000 points / 50,000 points / 20ms 100 kS/s	Connection	Displays the co	onnection diagra	am and the vo	ltage/curre	nt vector dia	ıgram
#The values are displayed for each measurement line pattern of combined connections MM screen Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen, Current Measurement screen, Power Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Trigger Record Length Compression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording time Recording speed / Recording length 1,000 points / 5,000 points / 5,000 points / 10,000 points / 50,000 points 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording length 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 50kS/s 20ms 100ms 500ms 10kS/s 10ms 50ms 100ms 25kS/s 40ms 200ms 400ms 200ms 10kS/s 100ms 500ms 1000ms 50kS/s 20ms 100ms 5000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option	check screen						be checked.
Basic Measurement screen, Voltage Measurement screen, Current Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Display pattern: 3 efficiency items, 3 loss items. Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen **Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Compression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording time Recording speed / Recording length 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 10ms 50ms 1000ms 5000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option	Connection display screen						ections
Measurement screen, Power Measurement screen Bar Graph screen, List screen, Vector screen Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen easurement is performed * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Record Length Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement if (FFT calculation) result when noise measurement is performed Recording speed 1,000 points / 10,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording speed 1,000 points 5,000 points 10,000 points 50,000 points 50,000 points 50,000 points 10,000 points 10,000 points 50,000 points 10,000 points	DMM screen						
Selects and displays any 4, 8, 16, or 32 measurement items from all basic measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Synchronization timing of harmonic synchronization source 1,000 points / 5,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording time Recording speed / Recording length 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 500ms 50kS/s 20ms 100ms 200ms 100ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Y Plot screen Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option		Measurement s	screen, Power M	leasurement			
measurement items Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Display pattern: 2 items (8 items, or 32 items) Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the woltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the woltage/current waveform	Harmonic screen	*					
Display pattern: 4 items, 8 items, 16 items, or 32 items (4 pattern switching) Displays the numerical values of efficient and loss set in the calculation algorithm Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen *Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Compression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording time Recording speed / Recording length 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 50kS/s 25kS/s 40ms 200ms 1000ms 25kS/s 40ms 200ms 100ms 500ms 10kS/s 100ms 500ms 1000ms 5000ms 25kS/s 40ms 200ms 1000ms 5000ms 10kS/s 100ms 500ms 1000ms 5000ms 25kS/s 40ms 200ms 1000ms 5000ms 25kS/s 40ms 200ms 1000ms 5000ms 10kS/s 100ms 500ms 1000ms 5000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 10kS/	Select/Display			10, or 32 m	casurement	neins from	an dasic
Display pattern: 3 efficiency items, 3 loss items. Display pattern: 3 efficiency items, 3 loss items. Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length Diomoints / 50,000 points / 10,000 points / 50,000 points x all voltage/current channels of the properties of	screen			ns, 16 items,	or 32 items	(4 pattern sv	witching)
Displays the voltage/current waveforms sampled at 500 kHz in a compressed screen * Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Record Length 2000 points / 50,000 points / 10,000 points / 50,000 points x all voltage/current channels 2000 points / 50,000 points / 50,000 points x all voltage/current channels 2000 points / 50,000 points / 50,000 points x all voltage/current channels 2000 points / 50,000 points / 50,000 points / 50,000 points / 50,000 points 2000 points / 50,000 points	Efficiency/Loss					e calculation	algorithm
* Displays the waveform and noise measurement (FFT calculation) result when noise measurement is performed Trigger Synchronization timing of harmonic synchronization source Record Length 1,000 points / 50,000 points / 10,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression) Recording speed / Recording speed / Recording length 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 500ms 50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms Y Plot screen Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option	Naveform & Noise					in a compress	ed screen
Trigger Synchronization timing of harmonic synchronization source 1,000 points / 5,000 points / 10,000 points / 50,000 points x all voltage/current channels 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression)	Measurement screen						
1,000 points / 5,000 points / 10,000 points / 50,000 points × all voltage/current channels		measurement is p	performed				
Variable Compression Ratio 1/1, 1/2, 1/5, 1/10, 1/25, 1/50 (Peak-Peak compression)							at obone -1
Recording speed Recording length 1,000 points 5,000 points 10,000 points 50,000 points 50,000 points 50,000 points 50,000 points 50,000 points 50,000 points 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 200ms 1000ms 25kS/s 20ms 100ms 200ms 400ms 25kS/s 40ms 200ms 400ms 200ms 10kS/s 100ms 500ms 1000ms 5000ms 10kS/s 100ms 500ms 1000ms 5000ms 10kS/s 10ms 500ms 1000ms 5000ms 1000ms 10000ms 1000ms 1000ms 1000ms 1000ms 1	_						ii channels
Recording length 1,000 points 5,000 points 10,000 points 50,000 points 500kS/s 2ms 10ms 20ms 100ms 250kS/s 4ms 20ms 40ms 200ms 100kS/s 10ms 50ms 100ms 50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 200ms 10kS/s 100ms 500ms 1000ms 500ms 10kS/s 100ms 500ms 1000ms 5000ms 10kS/s 100ms 500ms 1000ms 5000ms 1000ms 5000ms 1000ms 5000ms 1000ms 5000ms 1000ms 5000ms 1000ms	Recording time				Ī		
500kS/s	Ü		1,000 points	5,000 point	s 10,000	points 50,00	00 points
100kS/s 10ms 50ms 100ms 500ms 50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms 10kS/s 100ms 500ms 1000ms 5000ms 1000ms 5000ms 1000ms 5000ms 1000ms 5000ms 1000ms			2ms	10ms	20n	ns 1	00ms
50kS/s 20ms 100ms 200ms 1000ms 25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Y Plot screen		250kS/s	4ms	20ms	40n		
25kS/s 40ms 200ms 400ms 2000ms 10kS/s 100ms 500ms 1000ms 5000ms Y Plot screen Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option Horizontal axis: 1 item (with gauge display)					+		
Y Plot screen Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option Horizontal axis: 1 item (with gauge display)							
Y Plot screen Selects items on the horizontal and vertical axes from the basic measurement items and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option Horizontal axis: 1 item (with gauge display)							
and displays them in the X-Y graph *The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option Horizontal axis: 1 item (with gauge display)	V V Dlot core						
*The graph is drawn at the data update rate, data is not recorded, and drawing data is cleared Option Horizontal axis: 1 item (with gauge display)	x-1 Plot screen						
		*The graph is drav	vn at the data upda	te rate, data is no		nd drawing data	is cleared
Vertical axis: 2 items (with gauge display)	Option		, .)		
		vertical axis: 2	items (with gai	uge display)			

	Displays the measured values of the MOTOR TESTING OPTION 9791 (9793). Display pattern: Displays the numerical values of 4 items
3. Data save	Comments to the CE and the children
Auto data save Save destination	Saves each measured value to the CF card at each interval OFF / CF card (cannot be saved to the USB memory), the save destination folder can be specified
Save itemAuto	and peak value of the noise measurement function
	CSV file format
Manual data Save	Saves each measured value to each save destination when the SAVE key is pressed USB memory / CF card, the save destination folder can be specified
Save itemSave	
Data format	-
Screen hard copy	Saves the display screen to the save destination when the COPY key is pressed
Save destination	USB memory / CF card * The save destination folder can be specified when USB memory or CF card is specified
Data format	Compressed BMP format (256 colors)
Setting data save	Setting information can be saved and loaded to and from the save destination as a setting file (With the exception of language setting and communication setting)
Save destination	USB memory / CF card (the save destination folder can be specified)
	nected equipment
Synchronized	The 3390 master and 3390 slaves can be connected with synchronization
measurement	cables to perform synchronized measurements * If the interval setting is identical, synchronized measurements can be
Synchronized item	
Event item	data reset, event Hold, manual save, screen copy
Synchronization timing	Clock, data update rate, start/stop, data reset, event (During operation of the
Cumphronization dalou	master by the key or via communication)
Synchronization delay Temperature measurement	Up to 5 µs per connection, up to +50 ms per event Acquires the measured temperature values from the thermometer connected.
Applicable thermometer	to the RS-232C interface
Number of channels	HIOKI thermometers capable of communication via RS-232C
	1 channel
5. System	Facilish / Language / Chinasa
Display language Clock function	English / Japanese / Chinese Auto Calendar, Auto Leap Year Adjustment, 24 Hour Meter
Clock setting	Year, Month, Day, Hour, Minute Setting, Zero Second Adjustment
Real time accuracy	Within ±3 s / day (25°C)
Beep tone	OFF / ON
Screen color	COLOR1 / COLOR2 / COLOR3 / COLOR4 / MONO
Start screen select	Connection screen / screen closed in the previous session (Measurement screen only
LCD backlight	ON / 1min / 5min / 10min / 30min / 60min
Sensor recognition	Automatically recognizes the current sensor connected
Alarm display	Voltage/current peak over threshold detection, synchronization source non detection (Alarm mark on)
Key lock	ESC key: ON/OFF by holding down the key for 3 seconds (Key lock mark on)
System reset	Sets the equipment to the default (factory) settings (Communication setting
	are not changed)
File manipulation	are not changed) Media data list display, media formatting, new folder creation, folder file deletion, file copy between media
	Media data list display, media formatting, new folder creation, folder fildeletion, file copy between media
General spe	Media data list display, media formatting, new folder creation, folder fild deletion, file copy between media cifications
General spe	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media
General spe Operating location Storage temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder fild deletion, file copy between media cifications
General spe Operating location Storage temperature and humidity ranges Operating temperature	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2
General spe Operating location Storage temperature and humidity ranges Operating temperature	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation)
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case
General specific operating location Storage temperature and humidity ranges Operating temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input
General specific operating location Storage temperature and humidity ranges Operating temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface
General specific operating location Storage temperature and humidity ranges Operating temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B
General specific operating location Storage temperature and humidity ranges Operating temperature and humidity ranges	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface
General specific operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media Cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard Rated power supply voltage	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard Rated power supply voltage Maximum rated power	Media data list display, media formatting, new folder creation, folder file deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) O°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard Rated power supply voltage Maximum rated power	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard Rated power supply voltage Maximum rated power Dimensions Weight	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) O°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B) CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz 140VA 340 W × 170 H × 157 D mm (13.39" W × 6.69" H × 6.18" D)
General spe Operating location Storage temperature and humidity ranges Operating temperature	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz 140VA 340 W × 170 H × 157 D mm (13.39" W × 6.69" H × 6.18" D) (excluding protrusions) 4.8 kg (169.3 oz.) (including the 9793) About 10 years (a reference value of a lithium ion battery used at 23°C to
General spe Operating location Storage temperature and humidity ranges Operating temperature and humidity ranges Withstand voltage Applicable standard Rated power supply voltage Maximum rated power Dimensions Weight	Media data list display, media formatting, new folder creation, folder fil deletion, file copy between media cifications Indoors, altitude up to 2000 m, contamination class 2 -10°C to 50°C, 80%RH or less (No dew condensation) 0°C to 40°C, 80%RH or less (No dew condensation) For 15 seconds at 50/60 Hz AC5.312 kVrms: Between the voltage input terminal and the unit case AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface AC370 Vrms: Between the 9791 and 9793 input terminals (CH A, CH B CH Z) and the unit case Between CH A and CH B / CH Z Safety: EN61010 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3 100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz 140VA 340 W × 170 H × 157 D mm (13.39" W × 6.69" H × 6.18" D) (excluding protrusions) 4.8 kg (169.3 oz.) (including the 9793) About 10 years (a reference value of a lithium ion battery used at 23°C to back up the clock, setting conditions, and integrated values)

Basic calc	ulation alg	orithms				
Connection	1P2W	1P3W	3P3W2M	3P3W3M	3P4W	
Voltage and current RMS value (True RMS value)	$\sqrt{\frac{1}{M}\sum_{s=0}^{M-1} \left(X_{(i)s}\right)^2}$		$+ Xrms_{(i+1)}$	$ Xrms_123 = \frac{1}{3} (Xrms_1 + Xrms_2 + Xrms_3) $		
Voltage and current average rectified RMS indication value		$\frac{1}{2} \left(Xmn_{(i)} - \frac{1}{2} \right)$		$ Xmn123 = $ $ \frac{1}{3} (Xmn_1 + Xmn_2 + Xmn_3) $		
Voltage and current alternating-current component		Xac(i) =	$\sqrt{\left(Xrms_{(i)}\right)^2}$ –	$(Xdc_{(i)})^2$		
Voltage and current mean value		$Xdc(i) = \frac{1}{1}$	$\frac{1}{M} \sum_{s=0}^{M-1} X_{(i)s}$			
Voltage and current fundamental wave component	Fundamenta	Fundamental wave value X1(i) based on the harmonic calculation result				
Voltage and current peak value	Maximum value among X pk+(i) = X (i)s M Minimum value among X pk-(i) = X (i)s M					
Active power	$\begin{aligned} P(i) &= \\ \frac{1}{M} \sum_{s=0}^{M-1} (U_{(i)s} \times I_{(i)s}) \end{aligned}$	P12 = P34 =	P1+P2 P3+P4	P123 =P	1+P2+P3	
7 Ouro porror	in the cases of 3P3W3M and 3P4W connections, phase voltage is used for the voltage waveform U (i)s. (3P3W3M: U1s = (U1s-U3s)/3, U2s = (U2s-U1s)/3, U3s = (U3s-U2s)/2) The polarity symbols of active power P indicate the power direction when power is consumed (+P) and when power is regenerated (-P).					
Apparent power	$S(i) = U(i) \times I(i)$	$\begin{array}{c c} S_{12} = S_1 + S_2 \\ S_{34} = S_3 + S_4 \\ S_{34} = \frac{\sqrt{3}}{2}(S_1 + S_2) \\ S_{34} = \frac{\sqrt{3}}{2}(S_3 + S_4) \end{array}$				
	Selects rms or mn for U(i) and I(i) In the cases of 3P3W3M and 3P4W connections, phase voltage is used for the voltage U (i)					
	$Q(i) = \frac{1}{si_{(i)}\sqrt{S_{(i)}^2 - P_{(i)}^2}}$		Q1+Q2 Q3+Q2	Q123 =Q1+Q2+Q3		
Reactive power The polarity symbol si of reactive power Q indicates symbol [none]: lag and symbol [-]: lead. The polarity symbol si(i) is determined by lag or lead of voltage waveform U (i)s and current waveform I i measurement channel (i), and in the cases of 3P3W3M and 3P4W connections; phase voltage is used for waveform U (i)s.						
Power factor	$ \lambda(i) = \\ si_{(i)} \frac{ P_{(i)} }{ S_{(i)} } $	$\lambda_{12} = si_{12} \left \frac{P_{12}}{S_{12}} \right ,$	$\lambda_{34} = si_{34} \left \frac{P_{34}}{S_{34}} \right $	$\lambda_{123} = si$	$\frac{P_{123}}{S_{123}}$	
	 The polarity symbol si of power factor λ indicates symbol [none]: lag and symbol [-]: lead. The polarity symbol si(i) is determined by lead or lag of voltage waveform U (i)s and current waveform I (i)s for each measurement channel (i), and si12, si34, and si123 are determined by the symbol of Q12, Q34, and Q123, respectively. 					

Connection Item	1P2W	1P3W	3P3W2M	3P3W3M	3P4W	
Phase angle	$ \begin{vmatrix} \varphi(i) = \\ si_{(i)}cos^{-1} \lambda_{(i)} \end{vmatrix} $	$ \begin{vmatrix} \phi_{12} = \sin_{12}\cos^{-1} \lambda_{12} \\ \phi_{34} = \sin_{4}\cos^{-1} \lambda_{34} \end{vmatrix} $				
	The polarity symbol si(measurement channel. si12, si34, and si123 are	orm U (i)s and current v	vaveform I (i)s for each			
(i): Measurement channel, M: Number of samples between synchronization timings, s: Sample point number						

Motor analysis calculation algorithm						
Item	Setting unit	Calculation algorithm				
	V (DV voltage)	$\frac{1}{M}\sum_{s=0}^{M-1} A_s$				
chA	N• m / mN• m / kN• m	When analog DC	A [V] × chA scaling setpoint			
0.2	common (torque)	When frequency	(Measurement frequency - fc setpoint) × rated torque setpoint / fd setpoint			
	M: Number of samp	les between sync	hronization timings, s: Sample point number			
	V (DC voltage)	$\frac{1}{M}\sum_{s=0}^{M-1}B_s$				
	Hz (frequency)	When analog DC	B[V] × chB scaling setpoint			
chB		When pulse input	Pole number setpoint x pulse frequency / 2 × pulse number setpoint			
	r/min (rotation)	When analog DC	B[V] × chB scaling setpoint			
		When pulse input	2 × 60 × frequency [Hz] / pole number setpoint			
	N• m (unit of chA)	(Indicated value	of chA) \times 2 \times π \times (indicated value of chB) / 60			
	mN• m (unit of chA) (Indicated value of chA) $\times 2 \times \pi \times$ (indicated value of chB) / 60					
Pm	kN• m (unit of chA)	(Indicated value of chA) $\times 2 \times \pi \times$ (indicated value of chB) $\times 1000 / 60$				
	Calculation cannot be performed when the unit of chA is other than the above, or the unit of chB is other than r/min.					
	Hz (unit of chB)	100 × input frequency – indicated value of chB / input frequency				
Slip	r/min (unit of chB)	$100 \times 2 \times 60 \times \text{input frequency} - \text{indicated value of chB} \times \text{pole}$ number setpoint / $2 \times \pi \times \text{input frequency}$				
	Selects the input frequency from f1 to f4					

■ Current sensors specifications (Accuracy guarantee period of 1 year with the exception of the 9709 for 6 months)

Model	9272-10	9277	9278	9279 (Non-CE mark product)	
Rated current	AC 20A/200A	AC/DC 20A	AC/DC 200A	AC/DC 500A	
Maximum continuous input range	50A/300A rms	50A rms	350A rms	650A rms	
Accuracy (45 to 66 Hz, DC: DC compatible sensor)	±0.3%rdg.±0.01%f.s., ±0.2°	$\pm 0.5\%$ rdg. $\pm 0.05\%$ f.s. , $\pm 0.2^{\circ}$ (30 minutes after power is turned on and after magnetization)			
Frequency	1Hz to 5Hz: ±2%rdg.±0.1%f.s.		DC to 1kHz	: ±1.0% (±0.5°)	
characteristic	1kHz to 5kHz: ±1%rdg.±0.05%f.s. (±1.0)°	1 k to 50 kHz: ±2	.5 % (±2.5°)	1 k to 10 kHz: ±2.5 % (±2.5°)	
	10kHz to 50kHz: ±5%rdg.±0.1%f.s.	50 k to 100 kHz: ±	5.0 % (±5.0°)	10 k to 20 kHz: ±5.0 % (±5.0°)	
Note1 Effect of	±0.2%rdg. or less	±0.2%rdg. or less	±1.5%rdg. or less	±1.5%rdg, or less	
conductor position	(at 100A/55Hz input, using with the wire 10mm diameter)	(DC,55Hz)	(DC,55Hz)	(DC,55Hz)	
Operating temperature and	100mA or less	Max. 0.2A	Max. 1A	Max. 2A	
humidity	(in an AC electromagnetic field of 400 A/m, 60Hz)	(400 A/m, 55Hz and DC)	(400 A/m, 55Hz and DC)	(400 A/m, 55Hz and DC)	
Operating temperature and	0°C to 50°C (-32°F to 122°F)	0°C to 40°C (-32°F to 104°F)			
humidity	80%RH or less (No condensation)	80%RH or less (No condensation)			
Measurable conductor diameter	ф 46mm (1.81")	ф 20mm (0.79") ф 40mm (1.57")		ф 40mm (1.57")	
Dimensions/weight	78W×188H×35Dmm(3.07"W×7.40"H×1.38"D), 430g(15.2 oz.)	176W×69H×27Dmm(6.93"W×2.72"H×1.06"D), 470g(16.6 oz.)		220W×103H×43.5Dmm(8.66"W×4.06"H×1.71"D), 470g(16.6 oz.)	

Model	CT6862	62 CT6863 9709		CT6865		
Rated current	AC/DC 50A	AC/DC 200A	AC/DC 500A	AC/DC 1000A		
Maximum continuous input range	100A rms	400Arms	700A rms	1200A rms		
Accuracy (45 to 66 Hz, DC: DC compatible sensor)	±0.05 %rdg,±0.01 % f.s. , ±0.2° (Right after power is turned on at DC and 16Hz to 400Hz)		±0.05 %rdg.±0.01 % f.s. , ±0.2° (10 minutes after power is turned on)	±0.05 %rdg.±0.01 % f.s. , ±0.2°		
Frequency characteristic		rdg.±0.02%f.s.(±0.3°) rdg.±0.02%f.s. (±1.0°)	DC to 45Hz: ±0.2%rdg.±0.02%f.s.(±0.3°) 5kHz to 10kHz: ±2%rdg.±0.1%f.s. (±2.0°)	DC to 16Hz: $\pm 0.1\%$ rdg. $\pm 0.02\%$ f.s.($\pm 0.3^{\circ}$) 500Hz to 10kHz: $\pm 5\%$ rdg. $\pm 0.05\%$ f.s.		
Note1	500kHz to 1M Hz: ±30%rdg.±0.05%f.s. Note2	300kHz to 500k Hz: ±30%rdg.±0.05%f.s. Note2	20kHz to 100kHz: ±30%rdg,±0.1%f.s. (±30°)	10kHz to 20kHz: ±30%rdg.±0.1%f.s.		
Effect to	±0.01%rdg. or less (50A input, DC to	±0.01%rdg. or less (100A input, DC to	±0.05%rdg. or less (at 100ADC input,	±0.05%rdg. or less (1000A input, 50/60Hz, using with the wire 20mm diameter)		
conductor position	100Hz, using with the wire 5mm diameter)	100Hz, using with the wire 10mm diameter)	using with the wire 10mm diameter)			
Effect of external	10mA or less	50mA or less	50mA or less	200mA or less		
electromagnetic field	Scaled value, in a DC or 60Hz magnetic field of 400 A/m					
Operating temperature and	CT6862/CT6863/CT6965: -30°C to 85°C (-22°F to 185°F), 9709: 0°C to 50°C (-32°F to 122°F)					
humidity	80%RH or less (No condensation)					
Measurable conductor diameter	ф 24mm (0.94")	ф 24mm (0.94")	ф 36mm (1.42")	ф 36mm(1.42")		
Dimensions/weight	70W×100H×53Dmm (2.76"W×3.94"H×2.09"D),		160W×112H×50Dmm (6.30"W×4.41"H×1.97"D),			
Difficitions/weight	CT6862: 340g(12.0 oz.)	, CT6863: 350g(12.3oz.)	9709: 850g(30.0oz.) CT9895: 1000g(35.3oz)			

Note1 : Includes derating characteristics Note2: No phase precision regulations

POWER ANALYZER



POWER ANALYZER 3390

Accessories: Instruction Manual × 1, Measurement Guide × 1, Power cord × 1, USB cable × 1, D-sub connector × 1 (when 9792 or 9793 is installed), Color label × 2

Ordering Information

Please purchase separately-sold voltage cord and current sensor for measurements.

A HIOKI-issued PC card is also necessary in order to save measured data.

Factory options cannot be installed after delivery.

CAT III 1000V

CAT IV 600V

Voltage Cord L9438-50

Length: 3m (9.84ft); Red x 1, black x 1

Factory options (please specify at the time of order)



- **MOTOR TESTING OPTION 9791**
- D/A OUTPUT OPTION 9792
- MOTOR TESTING & D/A OUTPUT OPTION 9793

Options for voltage measurements



Voltage Cord L1000

Length: 3m (9.84ft); Red x 1, yellow x 1, blue x 1, gray x 1, and black x 4

Indoor wiring in buildings and factories for measurements up to 1000 V; can also be used for internal voltage measurements of equipment up to 1000 V.



Grabber Clip 9243

Usage:

Attaches to the end of the Voltage Cord L1000 or L9438-50.




WIRING ADAPTER PW9000

For 3P3W WIRING



WIRING ADAPTER PW9001 For 3P4W WIRING

Reduce voltage cords for easy wiring





PW9001 connection example When used with Model L1000

Note:

or PW9001

Dedicated PC application software and communication command manual are available for the **3390**. Please download them from the HIOKI

Rack mounts available on special order. Please contact your local HIOKI office or distributor.

When using the 3390 with a DC power supply as in the case of onvehicle measurements, a separate DC-AC converter is required.

Required DC-AC converter output specification Sinusoid wave type, 50/60 Hz (60 Hz recommended) Output type

Output capacity: The maximum power consumption of the 3390 is 140VA. Select a rating more than the capacity.

Options for current measurements

 AC/DC CURRENT SENSOR CAT III 1000V CAT III 1000V



CT6862 (AC/DC 50A)







UNIVERSAL CLAMP ON CT

CAT III 1000V



C16865 (AC/DC 1000A)

CLAMP ON SENSOR



9277 (AC/DC 20A)

Not CE-marked

9278 (AC/DC 200A)

9279 (AC/DC 500A)

9272-10 (AC20/200A) PC Card



PC Card Precaution Compatibility and performance are not guaranteed for PC cards made by other manufacturers. You may be unable to read from or save data to such cards.

9830 (Capacity: 2 GB)

PC Card 256M 9727 (Capacity: 256 MB) PC Card 512M 9728 (Capacity: 512 MB) 9729 (Capacity: 1 GB) PC Card 1G





CASE 9794 Hard case dedicated to the 3390

448 W × 618 H ×295 D mm (17.64" W × 24.33" H × 11.61" D) (excluding protrusions)

Connection cables



PC Card 2G

CONNECTION CORD L9217 Length: 1.5m (4.92ft)

For input of the 9791 and 9793



CONNECTION CABLE 9683 Length: 1.5m (4.92ft)

Usage: For synchronized measurement



LAN CABLE 9642 **Length**: 5m (16.41ft) supplied with straight to cross conversion cable

Combination example

1.General measurements (Three-phase three-wire (3P3W3M) single-circuit)















2.Inverter input and output evaluation and measurements (Three-phase there-wire (3P3W2M) two-circuit)



ANALYZER 3390 × 1











3.Motor evaluation and measurements (DC input / three-phase motor evaluation (DC, 3P3W3M measurements))









9709 × 4





Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies

HIOKI E.E. CORPORATION

Headquarters: 81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 http://www.hioki.co.jp / E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION:

6 Corporate Drive, Cranbury, NJ 08512 USA TEI +1-609-409-9109 / FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com

HIOKI (Shanghai) Sales & Trading Co., Ltd.: 1608-1610,Shanghai Times Square Office, 93 Huai Hai Zhong Road Shanghai, P.R.China POSTCODE: 200021 TEL +86-21-63910090/63910092 FAX +86-21-63910360 http://www.hioki.cn / E-mail: info@hioki.com.cn

Beijing Office : TEL +86-10-84418761 / 84418762 Guangzhou Office : TEL +86-20-38392673 / 38392676

HIOKI INDIA PRIVATE LIMITED:

Khandela House, 24 Gulmohar Colony Indore 452 018 (M.P.), India
TEL +91-731-4223901, 4223902 FAX +91-731-4223903

http://www.hioki.in / E-mail: info@hioki.in

HIOKI SINGAPORE PTE. LTD. : 33 Ubi Avenue 3, #03-02 Vertex, Singapore 408868 TEL +65-6634-7677 FAX +65-6634-7477

DISTRIBUTED BY